




Magnet Powerbank 10000 Saver

Quick Guide

320-97

Support helpdesk.sandberg.world

Charge Powerbank





Magnet Powerbank 10000 Saver

Item no. 320-97

www.sandberg.world

info@sandberg.world

Sandberg A/S

Bregnerødvej 133D,


3460 Birkerød, Denmark

Made in China



NOTE: If not used regularly, please recharge the powerbank at least every 3 months to maintain optimal performance.

Charge devices by cable



Charge devices wirelessly

